

STEP 1

TRIM

Measure your window and then the temporary shade. Trim the excess width from the shade. If your window is larger than the width of the temporary shade, you can easily use multiple shades to cover your window by hanging them side by side.



PEEL

STEP 2

Once your temporary shade is cut to the right size, peel back the stick at the top. Under the paper sticker, there is adhesive.

STEP 3

HANG & CLIP

Position the temporary shade over your window and stick the adhesive to the window frame, making sure the window is completely covered. Then use the plastic clip to shorten the length to fit your window.

And that's it!

