



Installation Guide: *Click2Fit Blackout Roller*

Cordless Lift | Motorization


HARDWARE AND PARTS INCLUDED



HEADRAIL LIGHT
BLOCKING STRIP



END CAPS



SIDE TRACKS



LIGHT
SEALING STRIP


TOOLS REQUIRED



LEVEL



TAPE MEASURE



STEP LADDER


INSTALLATION

1

Start by turning the headrail around and attaching the Headrail Light Blocking Covers.





Back of headrail



2

Turn the headrail around with the valance facing the front. Attach the side rails to the channels on each side of the headrail.



Make sure the support rod is on the outside of the headrail boot.



3


With both rails attached, lift the full assembly into the window.

Make sure the lever is not pressed in during installation so the headrail will fit into the opening. Push the lever to click in place while holding the headrail up to the top of the window opening.




4

Attach the bottom cap to each of the side tracks to ensure there is no damage to the bottom of the window opening.




Make sure the side track is set slightly back in the window, about 1/4". Insert the bottom Click2Fit rail with the flange in the front, then rotate it towards you so the bottom lies flat on the bottom of the window sill.




5

Push the lever down and lock it in place.


Test out the shade and adjust as needed for smooth operation.



OPTIONAL INSTALLATIONS



If you have gaps, add the included Light Sealing Strip to the outside edge of the side tracks to block additional light.



Peel the adhesive strip on the back of the side channels and attach the blackout skirt to block additional light.

CLEANING INSTRUCTIONS

1

For regular maintenance, use a duster or a vacuum with a brush attachment and run it over the front and back of the shade.

2

To spot clean stains, use a damp rag with a very mild, gentle detergent or soap. Dab at the affected spots; DO NOT RUB! Let the dampened area air dry and repeat as necessary.

3

All fabrics are different and some may be easier to clean than others. We recommend cleaning your shades as often as once a month.


PROGRAMMING AND USING THE REMOTE

Motorization Only


Quick pointers

The Motorized Shades are pre-programmed and arrive in Sleep Mode. Please wake the motor before attempting pairing and operation. These also will arrive with only 30% charge for safety reasons, so you may need to charge the product fully before first use.


Press and Hold the Setting Button for 6 Seconds until you hear the motor move and the lights on it flash red 4 times.





PAIRING THE REMOTE



REMOVING A SHADE FROM A CHANNEL

- 

1 Select the desired channel.
- 


2 Remove the battery cover by unscrewing the tiny screw and sliding it off.
- 


3 Press the "C" button quickly 3 times. The shade will jog and blink green to confirm.

SETTING AND REMOVING THE FAVORITE POSITION

Setting the Favorite

- 

1 Set the shade to the desired Favorite Position.
- 

2 Remove the battery cover by unscrewing the tiny screw and sliding it off.
- 


3 Press and hold the "L" Button, then quickly press and hold the Heart Button. The shade will beep and blink green to confirm.

Removing the Favorite

- 1 Press the Heart button to move the shade to the Favorite Position.
- 2 Follow steps 2-3 above to remove the shade's favorite.
- 3 Repeat steps for setting the Favorite Position above to set the new Favorite Position.


Change Motor Speed


- 


1 Ensure the remote is on the channel desired.
 - 

2 Hold the Heart button, then press the Up Button quickly. The Green light on the shade will blink confirmation.
- 
 3 Speeds: Standard, Comfort and Slow.

Changing the Battery

- 

1 Unscrew the small screw on the back battery cover and slide it off.
- 


2 Remove the old battery, and then install the new one with the Numbers and + sign facing up. Make sure it clips into the socket.
- 

3 Slide the battery cover back on and tighten the screw to secure it.

INSTALLING THE REMOTE'S WALL MOUNT

Optional

- 1 Find a spot where you would like to place the remote mount.
- 2 Mark where you will drill the screws and install the optional anchors. Screw the screws through the holes.
- 3 After they're installed, insert the cap over the screws.



TUISS SMARTVIEW APP

Downloading and Accessing the App

- 1 Search for the Tuiss SmartView app in the App Store or Google Play Store or Scan the QR code on the front of the swing label attached to your shades.
- 2 Open the app and follow the steps to Create an Account.
- 3 Tap Continue. When you open the app for the first time, you'll be asked by SmartView to use your phone's Bluetooth. Enable this and then continue.




Quick pointers

Waking the Shade


Wake the motor up by pressing and holding the Setting Button on the motor for 6 seconds. The light will flash 4 times. If you've already woken the motor to add the remote, you can skip this step.

Adding the Shade



- 1 Select "Add my first Blind". Scan the QR code on the Back of the swing label.
- 2 The blind will jog or move up and down briefly to acknowledge pairing.
- 3 Press "Found it!" and it will jog to confirm pairing.
- 4 Press Save, then Done if you have no further shades. If you want to add another, select "Add new Blind"

Operation



Selecting Open will move the shade to the top limit and Close to the bottom limit.

All shades assigned to the same room will move simultaneously.

To move individual shades, press the "Select blinds" option and then tick the box for the shade you'd like to use.

Drag the shade up or down to precisely position your shade.