



Installation Guide:**1% Solaris Patio Outdoor Zip Screen**

Cordless Lift | Motorization

HARDWARE AND PARTS INCLUDEDSIDE TRACKS, ZIP RAIL,
AND CHANNEL COVERS

END CAPS

REMOTE
(MOTORIZATION
ONLY)**TOOLS REQUIRED**

PENCIL



TAPE MEASURE



POWER DRILL



5/64" DRILL BIT




LEVEL



PHILLIPS DRILL BIT



PHILLIPS SCREWDRIVER




STEP LADDER


INSTALLATION**1**

Mark the channels with a pen or sharpie about 4 inches from each end. Then make a mark about 16 inches from your first marks or evenly space them.



Drill a hole at each mark using a 1/8" drill bit, then use a 3/8" drill bit for the upper portion of the channel.

**2**

Hold the channels in position and mark the screw holes and then predrill the holes for the anchors. Install the anchors.

**3**


Connect the side channels to the cassette and secure them in place.



4


Lift the entire shade and side rails into the opening and hold the shade in place. Screw in the side tracks to hold the shade in place. This would be the best point that additional assistance may be needed.

For the motorization version, install the motor-side side track first.




5

Slot the Zip Rail over the screw holes onto the fabric edges and slide it up in place. The fabric will slot through these channels to keep it taut.



6

Position the channel covers over the front of the channels. Slot them in until you hear them click in place.




Remote Instructions

Each motorized shade will include a 1 Channel Remote.

This remote will arrive pre-programmed so it will be ready to use right out of the box.

In order to operate, you'll need to plug in your shade directly into an outlet.



CLEANING INSTRUCTIONS

1

For regular maintenance, use a duster or a vacuum with a brush attachment and run it over the front and back of the shade.

2

To spot clean stains, use a damp rag with a very mild, gentle detergent or soap. Dab at the affected spots; DO NOT RUB! Let the dampened area air dry and repeat as necessary.

3

All fabrics are different and some may be easier to clean than others. We recommend cleaning your shades as often as once a month.