SelectBlinds

Installation Guide:
Designer Track Wood Shutters

Bypass Style Shutter

PARTS INCLUDED



Panels



Top Frame



Side Frames



Track Carriers



Carrier Wrench

Outside Mount Only



Top Frame Bracket



2" Support Bracket Screws

Optional



Panel Guide Bracket



Screws

Robertson Screws

2 1/4" Frame Screws

Phillips Screws

3/8" Valance Screws

TOOLS NEEDED



PHILLIPS SCREWDRIVER



ROBERTSON SCREWDRIVER



PENCIL



LEVEL



MALLET



POWER DRILL

Preparing the Top Frame

1 Before we start predrilling holes for the frame, you'll need to remove the tracks.

Unscrew all of the screws and take the tracks off of the top frame. Set these aside for now and we'll reattach them after we've installed the top frame.



2 For the top frame, it's recommended to predrill the holes 3" from each end and then evenly space them out from there. Be sure to not use the same holes as the tracks.



Quick pointers



On inside mount frames, you should predrill holes perpendicular to the frame.



On outside mount frames, you should predrill holes diagonally into the back ridge of the frame.

Attaching the Side Frames

The side frames are butt joined pieces. Preinstall these directly onto the top frame drilling a set of screws through the top down into each side frame.





Installing the Frame Assembly

When screwing in, start with a screw on the right or left ensuring it's drilled into a wall stud, then install the screw closest to the middle, and then on the opposite side. Make sure to attach all other screws, directly into a wall stud.



Attach the screws for the side frames 3" from the top and bottom and equally spacing the rest. Be sure to keep the frame peices square using a level.

Outside Mount Only

Attach a support bracket either flush with the back of the top of the frame or 1/8" from the edge. Make sure to place the bracket in line with each wall stud on the top of the frame and install them directly into wall first. Make sure not to place screws where the track screws will be installed.



Attach the screws through the support bracket into the top. This will ensure the frame will not sag from the weight of the shutter panels. Slide on the included covers for a clean look.



Reattaching the Track

1. Before reattaching the track to the top frame, slide in a set of carriers for each panel. There should be 2 per panel. While it is not required, we recommend alternating the sides the wheels are on for even operation.



2. Attach the track right up against the back of the top frame. Reattach it using the screws removed earlier.

3. Line the front track up with the front of the frame and reinstall it with the screws removed earlier. Make sure no carriers slide out while this is being installed.





Quick pointers

Bypass Track Placement for 2 Panels should look like the image below when installed correctly.



Bypass Track Placement for 3 Panels should have the track lined up with the back, front and placed directly in between them.



This would also be a great time to double-check that the frames are level. If the frame peices are unlevel, the panels may shift on their own or not close properly.



Attaching the Panels

1. Before attaching the panels, make sure to align each carrier with the others to the same height. This will make sure the panels are installed at an even level. Use the carrier adjustment wrench to raise them with a right turn, and lower with a left turn.



2. Open each carrier receiver on the top of the panels.



The panel will be correctly positioned if the tilt rod is facing towards you and should be installed from the back most panel, then each panel moving forward, numbered on the right.



3. Slide the carrier into the groove on the left side of the receiver and let the panel hang down to seat it in place.



4. Lock the latch on the top of the receiver to secure it to the carrier.



Quick pointers

For three panel bypass shutters, there will be light blocking strips included. To attach these, peel the back cover off the adhesive strip and attach it to the shutter in the order shown on the right.



One will be on the front of the back panel, the front and back of the middle panel, and the back of the front panel. Make sure to attach them starting with the back panel (1), then the middle (2), then the front (3).



Quick pointers

If your panel hangs uneven when next to the other panel or the floor, we recommend using the carrier wrench to raise/lower the panel. Use a level to ensure the frames are parallel with the edges of the panel. If they aren't they may need to be adjusted.

For bypass shutters with multiple panels per section, you may need to connect these together using inter-panel clips. These will be preinstalled on the left side of the right panel per pair of panels. These are clear to blend in with the panels. Start by clipping the panels together at the top and then work your way down from there.



SoftClose

These shutters have a SoftClose mechanism installed onto the top of the panels. These will need to be positioned so they catch on the square peg hanging down when shifting close. This will keep them from damaging the side frames during operation. These can be raised or lowered with a screwdriver so they are in line with the panels.



Optional Parts

Floor Guide

Screw the floor guide into the floor using the screw holes (shown on the right). Be sure to use a screw with a flat top for smooth operation. Turn the middle guide 90 degrees to the widest position for proper panel spacing.



The panels should pass through the two channels. This will keep it them from running into each other and reduce wear and tear.



Valance

Inside Mount

Line the valance up with the top of the top frame. Use a nail gun to secure the valance in place.

If you don't have a nail gun, we recommend using a tack hammer and finishing nails to secure it in place.



Valance

Outside Mount

1



Attach the valance bracket to the top of the frame with a 3/8" Screw. Space these 3" from the edge and then evenly from there.

2



Line the valance up just a bit higher than the valance bracket. You may need another set of hands for these next steps.

3



Use another 3/8" screw to attach the valance to the valance bracket.

Child Friendly

CLEANING INSTRUCTIONS

For regular maintenance, use a duster or a vacuum with a brush attachment and run it over the front and back of the shutter.