

# EDGE CUTOUT

Measuring for cutouts around obstructions on windows and doors (like backsplashes, counter tops, door knobs, latches, window cranks, etc.) is easy. Follow the instructions below to measure any cutouts on the right or left side of your window or door, or both sides if needed. Send the completed worksheet to [customercare@selectblinds.com](mailto:customercare@selectblinds.com). We'll take it from there and add it to your order to ensure a perfect fit.

*If you are ordering outside mount, make sure to add the recommended 2" - 4" to your total width BEFORE you fill out this worksheet.*

**A**

Measure the height from the top of your window to the top of the obstruction.

\_\_\_\_\_ inches

**B**


Measure the height of the obstruction from the bottom of your window to the top edge of the obstruction.

\_\_\_\_\_ inches

**C**

Measure the width of the obstruction from the inside edge of the window to the outside edge of the obstruction.

\_\_\_\_\_ inches



**D**

Measure the height from the top of your window to the top of the obstruction.

\_\_\_\_\_ inches

**E**

Measure the height of the obstruction from the bottom of your window to the top edge of the obstruction.

\_\_\_\_\_ inches

**F**

Measure the width of the obstruction from the inside edge of the window to the outside edge of the obstruction.

\_\_\_\_\_ inches

**G**

Measure the width above the obstruction(s).

\_\_\_\_\_ inches

**H**

Measure the width between the obstruction(s).

\_\_\_\_\_ inches

**IMPORTANT:** Filling this worksheet incorrectly may delay your order. Use the formulas below to check that everything adds up correctly.

**TOTAL WIDTH = G**  
**TOTAL WIDTH = C + F + H**

**TOTAL HEIGHT = A + B**  
**TOTAL HEIGHT = D + E**

**MAXIMUM CUT IN WIDTH per side**

**WOOD BLINDS - 4 inches\***

**FAUX WOOD BLINDS - 4 inches\***

**MINI BLINDS - 5 inches\***

\*If **C** or **F** exceeds this number, the cutout is not possible.

**FULL NAME**

**ORDER #**

**ROOM NAME**

**ORDER SIZE:**

\_\_\_\_\_ inches  
(TOTAL WIDTH)

**X**

\_\_\_\_\_ inches  
(TOTAL HEIGHT)

**SEND** completed worksheet to [customercare@selectblinds.com](mailto:customercare@selectblinds.com).

**Questions?** Contact us at **888-257-1840** or online at [www.selectblinds.com](http://www.selectblinds.com).

 **SelectBlinds®**  
Simple. Smart. Custom.

# NOTCH CUTOUT

Measuring for cutouts around obstructions on windows and doors (like backsplashes, counter tops, door knobs, latches, window cranks, etc.) is easy. Follow the instructions below to measure any cutouts on the right or left side of your window or door, or both sides if needed. Send the completed worksheet to [customercare@selectblinds.com](mailto:customercare@selectblinds.com). We'll take it from there and add it to your order to ensure a perfect fit.

*If you are ordering outside mount, make sure to add the recommended 2" - 4" to your total width BEFORE you fill out this worksheet.*

<p><b>A</b></p> <p>Measure the height from the top of the window to the top of the obstruction.</p> <p>_____ inches</p>		<p><b>E</b></p> <p>Measure the height from the top of the window to the top of the obstruction.</p> <p>_____ inches</p>	
<p><b>B</b></p> <p>Measure the width of the obstruction from the inside edge of the window to the outside edge of the obstruction.</p> <p>_____ inches</p>		<p><b>F</b></p> <p>Measure the width of the obstruction from the inside edge of the window to the outside edge of the obstruction.</p> <p>_____ inches</p>	
<p><b>C</b></p> <p>Measure the height of the obstruction.</p> <p>_____ inches</p>		<p><b>G</b></p> <p>Measure the height of the obstruction.</p> <p>_____ inches</p>	
<p><b>D</b></p> <p>Measure the height from the bottom of the window to the bottom of the obstruction.</p> <p>_____ inches</p>		<p><b>H</b></p> <p>Measure the height from the bottom of the window to the bottom of the obstruction.</p> <p>_____ inches</p>	
<p><b>I</b></p> <p>Measure the width between the obstruction(s).</p> <p>_____ inches</p>		<p><b>J</b></p> <p>Measure the full width above or below the obstruction(s).</p> <p>_____ inches</p>	

**IMPORTANT:** Filling this worksheet incorrectly may delay your order. Use the formulas below to check that everything adds up correctly.

**TOTAL WIDTH = J**  
**TOTAL WIDTH = B + F + I**

**TOTAL HEIGHT = A + C + D**  
**TOTAL HEIGHT = E + G + H**

## MAXIMUM CUT IN WIDTH per side

**WOOD BLINDS** - 4 inches\*  
**FAUX WOOD BLINDS** - 4 inches\*  
**MINI BLINDS** - 5 inches\*

\*If **B** or **F** exceeds this number, the cutout is not possible.

**FULL NAME**

**ORDER #**

**ROOM NAME**

**ORDER SIZE:**

\_\_\_\_\_ inches  
**(TOTAL WIDTH)**

**X**

\_\_\_\_\_ inches  
**(TOTAL HEIGHT)**

**SEND** completed worksheet to [customercare@selectblinds.com](mailto:customercare@selectblinds.com).

**Questions?** Contact us at **888-257-1840** or online at [www.selectblinds.com](http://www.selectblinds.com).

 **SelectBlinds®**  
Simple. Smart. Custom.