





GETTING STARTED

A few simple tools are required:

- Measuring tape
- Power drill, drill bits
- 1/4" Hex head and/or Phillips driver bit
- Pencil
- 5mm or 3/16" hex key



Additional fasteners other than those sent with your shading may be required depending on the mounting surface. Wallboard and plaster require the use of anchors such as expansion or toggle bolts. Brick, tile or stone need special plugs and drill bits. Remember to always pre-drill holes in wood to avoid splitting.



STEP 1: BRACKET INSTALLATION


Shadings are shipped with the required number of brackets for proper installation. End brackets should be located approximately 2" from either end. Depending on the width of the shading, additional brackets may be necessary, evenly spaced between the two end brackets.

Using the installation bracket as a template, measure to the edge of the bracket and mark the hole locations with a pencil for drilling.

Brackets must be in line and level. Shim brackets on inside mounts if necessary. The head rail must be level for the shade to operate properly.

| Shade Width | # of Brackets |
|-------------|---------------|
| Up to 40" | 2 |
| >40" - 72" | 3 |
| >72" - 84" | 4 |
| >84" and up | 5 |

Head Rail Shades




INSIDE MOUNT

The minimum mounting depth for an inside mount is 1".

A minimum of 3 3/4" is needed to fully recess the shading.

Make sure the brackets are level and aligned.

Attach using two screws.




Inside Mount

Shallow Mount - Minimum 1" surface
Flush Mount - Minimum 3 3/4" surface

OUTSIDE MOUNT

The minimum mounting height for outside mounted shadings is 1”.

Make sure the brackets are level and aligned.
Attach using two screws.




Outside Mount
Minimum 1” surface

SPACER BLOCKS (OPTIONAL)

Each spacer block projects brackets $\frac{3}{8}$ ” away from mounting surface.

Make sure the brackets are level and aligned.

Attach using two screws. Screws should be long enough to secure the bracket to the mounting surface.




Outside Mount with Spacer Blocks

EXTENSION BRACKETS (OPTIONAL)

Optional extension brackets are used to project the back of the shading up to 2 ½” from the mounting surface.

Attach the mounting bracket to the extension bracket with the nut and bolt provided.




Outside Mount with Extension Brackets
Minimum 2” surface

SIDE MOUNT (OPTIONAL)

Measure from window sill up to desired mounting position on each side of the window frame. Mark position.

Mount side mount brackets on each side of window frame as shown. Make sure to confirm the head rail will sit perfectly level.



Once side mount brackets are installed and properly positioned, attach the mounting brackets using the nuts and bolts provided.



Side Mount
Minimum 2” surface

STEP 2: SHADE INSTALLATION

Center the shading in the window opening and push the head rail into the mounting brackets as shown.



OPERATION


To Lower Shading: Pull down on the bottom rail strap until the shading reaches the desired length.

To Open Vanes: Lower the shading all the way down and continue pulling down on the strap until the vanes open.

To Raise Shading: Pull down on the strap slightly (about ¼") and then release. Note: on inside mounted shades you may need to pull the bottom rail away from the sill to pull down enough to release the lock.

Note: To reposition the shade, it must be raised several inches first (this resets the catch mechanism) and then pulled down to the new position.

When done operating shading, lift the pull ring toward the front of the bottom rail until the magnet holds it in place.



SKREW ADJUSTMENT (IF NECESSARY)



If the fabric is moving to one side as the shading is raised (skewing), first check that the installation brackets are level. Shim to level, if necessary. If the brackets are level it may be necessary to adjust the bottom rail weight.

There is a weight on either side of the bottom rail strap. Release the weight clips on the weight on the side of the shade where the fabric is gathering. To release the weight clip, insert a flat blade screwdriver into the weight clip and turn clockwise.


Move the weight in 1" increments toward the side where the fabric is gathering.

Secure the weight clips in position by turning them counterclockwise after making the adjustment.

Test and, if necessary, adjust again.



Release




TENSION ADJUSTMENT (IF NECESSARY)

If the shading does not go all the way up increase the spring tension.

If the shading goes up too quickly, decrease the tension.


Insert a ⅜" hex key through the hole in the left end cap and into the lifting spring.

Turning the hex key clockwise will increase the tension. Turning the hex key counter clockwise will decrease the tension.



APPLY END CAP LABEL

When any necessary tension adjustments are complete, apply the included head rail label over the hole in the end cap.




HOLD DOWN BRACKETS (OPTIONAL)

Lower the shading, keeping the vanes closed.

Place the magnetic hold down bracket onto the bottom rail just inside the end cap, oriented as shown.

Hold the bracket while opening and closing the vanes (it may be necessary to have someone assist you). Adjust the bracket to the best overall position.



Mark the screw location using the mounting options shown to the right.

The screw should be placed in the middle of the slot. This will allow for adjustment.

Drill the screw holes using a $\frac{3}{32}$ " drill bit.

IMPORTANT: Use drywall anchors when mounting into drywall.

OUTSIDE MOUNT



Preferred



Alternate

INSIDE MOUNT




Preferred



Alternate

Attach the hold down brackets to the mounting surface using the screws provided.

If necessary, adjust bracket height by loosening the screw and sliding the bracket up or down.




SHADING REMOVAL

If you need to remove your shading, follow the instructions below.

Partially lower the shading and insert a flat head screwdriver as shown.

Twist the screwdriver until the head rail disengages from the bracket.

As you release the brackets, support the head rail to keep it from falling.



CLEANING AND CARE

The shading fabric is easy to care for. Regular dusting with a feather duster or vacuum cleaner brush is recommended. Most stains can be blotted with a damp sponge and mild detergent. Before using anything stronger than mild detergent and lukewarm water, test an unobtrusive corner of the shade. If you have any questions, call your dealer for advice.